



LEDSHOW



MULTI ZONE Single Color Controller w/ Bluetooth & RF Remote

BLUETOOTH APP CONNECTION

- Download the app **LEDSHOW** in the app store (the icon is in the top right), then open the app. **DO NOT** connect to the device in your phone settings menu. If you do delete the app and reinstall.
- If connected your app should show connected to "**HYLEDTEST**" in the device menu (accessed in the top left of the app)
- If you do not see a connection in the devices, you may need to give permission to location access. To do this open your phone settings, go into app settings and find the LEDSHOW app. Once you find it go into the permissions and approve location access, Bluetooth and file access as well if not already approved. Once location access is given reboot the phone and open the app again.

FUCTIONS

- The controller should retain the last used setting when powered down and back up again.
- Zones control
 - When each zone is highlighted in the app in red only those zones will receive a new command. Non highlighted zones will retain the last command.
 - On remote press zone I or II once to turn control that zone, second time to turn off control of that zone.
 - To link multiple zones on the remote, press zone I and II in immediate order as quickly as possible
- Modes
 - Allows selection of patterns on the remote. BLINK, BREATHING, STATIC, STROBE, WIGWAG I, WIGWAG II

Troubleshooting: If the app will not connect but the remote works delete the app, pull fuse for 2 minute then re install the app while fuse is pulled. Ensure location access is granted for the app. See instructions above if you have not done this or if the app didn't request location access when installed.

Troubleshooting: If the app works but the remote does not replace batteries and pair remote to unit again.


Troubleshooting: If the remote doesn't work make sure to press the "I" and "II" button quickly together to link the two zones, until you press these buttons the remote will not work.

Pair Remote: Pull fuse, hold down off button, place fuse back in, continue to hold off button.

COURTESY / WHITE OVERRIDE

- Connect white wire to secondary switch or courtesy light power on the vehicle, this will turn the white lights on if the box has power even if the lights are turned off with the remote.

*There will be a slight power draw over long-term storage from the Bluetooth controller in stand by mode. We suggest putting on a switch, but it is not necessary or required.



5-INST-SINGLECOLOR-LEDSHOW



SINGLE COLOR 2 PIN Rock Lights


WIRING

LARGE RED WIRE: POWER

LARGE BLACK WIRE: GROUND

WHITE WIRE: WHITE/COURTESY OVERRIDE (NOT REQUIRED)

Single Color Controller
BT PHONE APP: LED SHOW & RF REMOTE



****Example configuration, configure any way you want****